

1 OCR function settings



^#SC^3030761

Turn on the OCR function of the scanner (default)



^#SC^3030760

Turn off the OCR function of the scanner

2 COL ID Card-PDF417 and COL ID Card-OCR settings



^#SC^6069300

Default output



^#SC^606930A

Output: NAME [TAB] GENDER



^#SC^6069301

Output: ID [TAB] NAME [TAB] GENDER [TAB] BIRD DATE



^#SC^6069302

Output: ID



^#SC^6069303

Output: ID [TAB]NAME



^#SC^6069304

Output: 3 [TAB]ID [TAB]NAME [TAB]GENDER [TAB]BIRD DATE



^#SC^6069305

Output: ID; NAME; GENDER; BIRD DATE



^#SC^6069306

Output: ID, NAME, GENDER, BIRD DATE



^#SC^6069307

Output: ID_NAME_GENDER_BIRD DATE



^#SC^6069308

Output: ID NAME GENDER BIRD DATE



^#SC^6069309

Original data output



^#SC^6069901

COL ID Card-PDF417 and COL ID Card-OCR need to fill in all four names (default)



^#SC^6069900

COL ID Card-PDF417 and COL ID Card-OCR no need to fill in all four names

3 COL PASSPORT settings



^#SC^6069601

Turn on reading COL PASSPORT-OCR (default)



^#SC^6069600

Turn off reading COL PASSPORT-OCR

4 COL OWNERSHIP CARD settings



^#SC^6069701

Turn on reading COL OWNERSHIP CARD-PDF417 (default)



^#SC^6069700

Turn off reading COL OWNERSHIP CARD-PDF417



^#SC^6069A01

COL OWNERSHIP CARD need to fill in all four names(default)



^#SC^6069A00

COL OWNERSHIP CARD no need to fill in all four names

5 COL DRIVER'S LICENSE settings



^#SC^6069801

Turn on reading COL DRIVER'S LICENSE -PDF417 (default)



^#SC^6069800

Turn off reading COL DRIVER'S LICENSE -PDF417